



Anziehvorschrift für Zylinderkopf		361.473	 Das Original
Tightening Instructions for Cylinder Head		passend für / suitable for adaptable à / adaptable a BMW	
Instructions de serrage pour culasse			
Prescripciones de apriete para culatas			
Schraubenkopf / Head shape Tête de vis / Cabeza de tornillo		Anziehreihenfolge/Tightening sequence/Ordre de serrage/Orden de apriete	
			
802.820 M 10 x 110			
Anziehen/ * 40 Nm Tightening/ ➤ 90° Serrage/ ➤ 90° Apriete			
Zeichenerklärung / Explanations / Explication / Explicacion			
* ★ ☐ ● ➤	neue Zylinderkopf-schrauben verwenden Warmlauf (80°C) Schrauben einzeln lösen und wieder anziehen Setzzeit Drehwinkel	use new cylinder head bolts warm up time (80°C) loosen and tighten each bolt relaxation time torque angle	utiliser des vis neuves chauffage (80°C) deserrer et serrer vis par vis durée de tassement angle de serrage emplar tornillos nuevos calentamiento (80°C) aflojar y apretar tornillo a tornillo tiempo de espera ángulo de giro
Motortyp / Engine type / Type de moteur / Tipo de motor			
Mot. M52/ M54 0,7 mm ÷ E46 323i,Ci, 325i,Ci,ti,xi, 328i,Ci, 330i,Ci,xi E39 523i , 525i , 528i, 530i E60 525i, 530i E61 525i E38 728i,iL E65 730i E66 730iL X3 2.5i, 3.0i			
ElringKlinger AG, Max-Eyth-Str.2 72581 Dettingen / Erms. Tel. 07123/724 601		*361.473*	